

A close-up, low-angle shot of a woman's face and head in profile, tilted back. She is in a shower, with water spraying from a showerhead above her. Her hair is wet and covered in white soap suds. Her eyes are closed, and she has a serene expression. The background is a blurred shower curtain.

EXOcare ML70

Sodium Laureth Sulfate (and)
Cocamide MEA

Local. Global. Integrated.

Description

- concentrated mixture of basic surfactants,
- especially recommended for use in cold-processed cosmetic formulations,
- easy-to-process blend,
- excellent cleaning, thickening, properties,
- foam stabilizer,
- recommended dose up to 20%,
- recommended pH of the final formulation 4.0 - 9.0.

Application

- liquid/gel hand soaps, shower gels,
- body wash, bath preparations,
- shampoos, hair conditioners,
- household detergents,
- dishwashing liquids.

in line with
cosmetic trends



guarantee the
consumer satisfaction



improvement of
Personal Care formulations



innovative
product



value
for money



EXOcure ML70

Sodium Laureth Sulfate (and) Cocamide MEA

Chemical name	Mixture of surfactants	
INCI name	Sodium Laureth Sulfate (and) Cocamide MEA	
Function	Cleaning, thickening, foaming agent, foam stabilizer	
Technical requirements	Appearance at temperature (20÷25)°C	viscous paste
	pH of 20% solution product	9.5 ÷ 11.5
	Anionic active matter, %(m/m)	48 ÷ 52
	Water, %(m/m)	28 ÷ 32
General data	Solubility in water	good
	Solidification point, °C	approx. 2
	Density at 25°C, g/mL	approx. 1.00

Hand soap gel [KD-43]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	up to 100	solvent
A	Sodium Laureth Sulfate, Cocamide MEA	EXOcare ML70	8.00	surfactant
A	Sodium Benzoate, Potassium Sorbate	–	0.50	preservative
A	Lactic Acid	–	0.25	pH adjuster
A	Allantoin	–	0.05	active
A	CI 17200	–	q.s	colorant
B	Parfum	–	0.30	fragrance
B	Cocamidopropyl Betaine	ROKamina K30K	4.00	surfactant
C	Sodium Chloride	–	0.70	thickener

Appearance	visual method	sticky gel
pH		4.6 - 5.3
Viscosity [cP]	Brookfield LV, spindle 34, speed 2.5 RPM, T: 25°C	3000 - 10000
Stability	1 month in 5°C, RT, 40°C	confirmed

Procedure:

1. Combine ingredients from phase A. Mix until uniform.
2. Add slowly Parfum and ROKamina K30K while mixing – mix until uniform. Mix until uniform.
3. Add slowly Sodium Chloride while mixing. Mix until uniform.

Cleansing body gel [KD-121]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	up to 100	solvent
A	Sodium Laureth Sulfate, Cocamide MEA	EXOcare ML70	5.00	surfactant
A	Sodium Benzoate, Potassium Sorbate	–	0.50	preservative
A	Lactic Acid	–	0.25	pH adjuster
A	PEG-7 Glyceryl Cocoate	ROKAcet KO300G	2.00	surfactant
B	Parfum	–	0.25	fragrance
B	Cocamidopropyl Betaine	ROKAmina K30	8.00	surfactant
C	Sodium Chloride	–	0.50	thickener

Appearance	visual method	viscous gel
pH		4.6 - 5.3
Viscosity [cP]	Brookfield LV, spindle 34, speed 2.5 RPM, T: 25°C	3000 - 10000
Stability	1 month in 5°C, RT, 40°C	confirmed

Procedure:

1. Combine ingredients from phase A. Mix until uniform.
2. Add slowly Parfum and ROKAmina K30 while mixing – mix until uniform.
3. Add slowly Sodium Chloride while mixing. Mix until uniform.

Urea shower gel [KD-123]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	up to 100	solvent
A	Sodium Laureth Sulfate, Cocamide MEA	EXOcare ML70	5.00	surfactant
A	Sodium Laureth Sulfate	SULFOROKAnol L270/1	8.00	surfactant
A	Glycerin	–	2.00	solvent
A	Sodium Benzoate, Potassium Sorbate	–	0.70	preservative
A	Lactic Acid	–	1.00	buffering agent
A	Sodium Lactate	–	1.40	buffering agent
A	Arginine	–	0.50	active
A	Urea	–	4.00	humectant
B	Parfum	–	0.50	fragrance
C	Cocamidopropyl Betaine	ROKAmina K30	6.00	surfactant
D	Sodium Chloride	–	1.50	thickener

Appearance	visual method	gel
pH		4.7 - 5.7
Viscosity [cP]	Brookfield LV, spindle 34, speed 2.5 RPM, T: 25°C	2500 - 10000
Stability	1 month in 5°C, RT, 40°C	confirmed

Procedure:

- 1. In a main vessel combine ingredients from phase A – mix until uniform (cloudy solution).
- 2. Prepare the remaining ingredients in a separate beakers.
- 3. Add ingredients from phase B – mix until uniform.
- 4. Add slowly ROKAmina K30 while mixing – mix until uniform.
- 5. Add slowly Sodium Chloride while mixing – mix until uniform.

Shampoo and conditioner 2 in 1 [KD-125]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	up to 100	solvent
A	Sodium Laureth Sulfate, Cocamide MEA	EXOcare ML70	12.00	surfactant
A	Zinc Coceth Sulfate	–	10.00	surfactant
A	Polyquaternium-7	–	1.00	film forming agent
B	Sodium Benzoate, Potassium Sorbate	–	0.50	preservative
B	Lactic Acid	–	0.25	pH adjuster
B	CI 77891, Mica	–	0.05	colorant
B	PEG-7 Glyceryl Cocoate	ROKAcet KO300G	1.00	surfactant
C	Sodium Laureth Sulfate, Cocamide DEA, Glycol Distearate	EXOpearl N	1.00	pearlescent agent
D	Parfum	–	0.50	fragrance
E	Cocamidopropyl Betaine	ROKAmina K30	6.00	surfactant
F	Sodium Chloride	–	0.50	thickener

Appearance visual method

pH

Viscosity [cP]

Stability

Brookfield LV, spindle 34, speed 2.5 RPM, T: 25°C

1 month in 5°C, RT, 40°C

pearly gel

4.7 - 5.5

5000 - 12000

confirmed

Procedure:

1. In a main vessel combine ingredients from phase A – mix until uniform (cloudy solution).
2. Prepare the remaining ingredients in a separate beakers.
3. Add ingredients from phase B – mix until uniform.
4. Add phase C-D ingredients while mixing – mix until uniform.
5. Add slowly ROKAmina K30 while mixing – mix until uniform.
6. Add slowly Sodium Chloride while mixing – mix until uniform.

Men body wash gel [KD-126]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	up to 100	solvent
A	Sodium Laureth Sulfate, Cocamide MEA	EXOcare ML70	19.00	surfactant
B	Acrylates Copolymer	–	6.00	rheology modifier
B	Aqua	–	6.00	solvent
C	Sodium Hydroxide	–	0.20	pH adjuster
C	Phenoxyethanol	–	0.80	preservative
D	Sodium Chloride	–	0.50	thickener
E	Petrolatum	–	3.00	emollient
F	Parfum	–	0.50	fragrance
G	CI 42090	–	q.s	colorant

Appearance	visual method	blue, viscous gel
pH		6.0 - 7.5
Stability	1 month in 5°C, RT, 40°C	confirmed

Procedure:

1. Combine ingerdients from phase A and B in separate vessel – mix until uniform.
2. Add slowly phase B ingredients to phase A while mixing – mix until uniform. In a separate vessels prepare others ingredients.
3. Add preservative and pH adjuster while mixing – mix until uniform.
4. Add phase E, F and G while mixing – mix until uniform.

Cooling shower gel [KD-127]

Phase	INCI name	Brand name	Concentration [%]	Function
A	Aqua	–	up to 100	solvent
A	Sodium Laureth Sulfate, Cocamide MEA	EXOcare ML70	18.00	surfactant
A	Betaine	–	1.00	active
A	Sodium Benzoate, Potassium Sorbate	–	0.60	preservative
A	Lactic Acid	–	0.20	buffering agent
A	Allantoin	–	0.10	active
A	CI 19140	–	q.s	colorant
A	CI 42090	–	q.s	colorant
B	Menthol	–	0.10	refreshing agent
B	Parfum	–	0.50	fragrance
B	PPG-5-Laureth-5	ROKAnol LP31	0.50	solubilizer
C	Sodium Chloride	–	1.00	thickener

Appearance	visual method	green gel
pH		4.7 - 5.5
Viscosity [cP]	Brookfield LV, spindle 34, speed 2.5 RPM, T: 25°C	2500 - 9000
Stability	1 month in 5°C, RT, 40°C	confirmed

Procedure:

1. In a main vessel combine ingredients from phase A – mix until uniform.
2. Combine ingredients from phase B – mix until uniform.
3. Add ingredients from phase B – mix until uniform.
4. Add slowly Sodium Chloride while mixing – mix until uniform.



This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.





PCC Exol SA

Sienkiewicza 4

56-120 Brzeg Dolny, Poland

products@pcc.eu

Please visit our capital group business platform:

www.products.pcc.eu



January 2026

The information in the catalogue is believed to be accurate and compiled to the best of our knowledge; however, it should be considered as introductory only. Detailed information about our products is available in TDS and MSDS.

The suggestions for product applications are based on our best knowledge.

The responsibility for the use of products in conformity or otherwise with the suggested application, and for determining product suitability for the user's own purposes rests with the user.

All copyright and trademark rights, as well as other intellectual and industrial property rights and the resulting rights to use this publication and its contents have been transferred to PCC Rokita SA or PCC EXOL SA or its licensors. All rights reserved.

Users/readers are not entitled to reproduce this publication in whole or in part, nor are they entitled to reproduce it (excluding reproduction for personal use) or to transfer it to third parties.

Permission to reproduce it for personal use does not apply to data used in other publications, electronic information systems, or other media publications. PCC Rokita SA and PCC EXOL SA shall not be responsible for data published by users.